

PALLITE VIII

Continuous, Very High Illuminance Floodlight

Features

- designed for industrial (not studio) environments
- very high illuminance level, 100,000 lux at 3 feet, 8" diameter spot
- camera lens port on axis of illumination
- wide area of source eliminates shadows
- ringlight construction

Applications

- ideally suitable for high speed image recording (photo, video and electronic imaging)
- industrial photography
- general photography within 1 to 2 metres requiring large area, very high, continuous illumination without shadows

Description

The PALLITE VIII is a continuous, and very high illuminance ring-shaped floodlight specifically designed for industrial and scientific high speed image recording applications. The incandescent ringling design keeps light on the optical axis for shadowless lighting, and thus provides maximum light for confined areas. The PALLITE VIII also permits lighting and shooting through a mirror into an otherwise inaccessible location.

The PALLITE VIII utilizes projection lamps with integral dichroic glass reflectors which reflect visible light, but transmit infrared radiation thus producing a relatively cool light source. Four different light levels can be achieved with the four toggle switches at the rear of the PALLITE VIII.

Although the PALLITE VIII requires max 24 amps, it can be used from ordinary electrical outlets of 15 amps because the total input is provided by two separate cords which can be connected to separate electrical outlets and circuits.

Specifications

- Maximum power 2400W of quartz halogen light at 3350K
- Maximum illumination 100,000 lux or 10,000 footcandles at 3 feet with a temperature of less than 160° F after ten minutes at subject. Area of max illumination, 2 feet diameter at 3 feet distance
- Four different power levels controllable with toggle switches 600W, 1200W, 1800W and 2400W
- Mounts on standard 5/8" stud
- Size: 9" diameter, 7" deep, 13" high
- Weight: 5 lbs 6 oz. with lamps
- Diameter of centre lens opening: 2-3/4" at rear and 3-1/4" at front of housing. Depth is 6 inches
- Power requirements: Operation from one or two different power outlets of 15 amps each

Ordering Information

PALLITE VIII continuous, very high illuminance floodlight supplied complete with a set of 8 lamps, cooling fans and 5/8" hole for mounting, 2 x 12 amps max. including two spare projection lamps. Light stand not included.

Accessories

- Heavy duty lightstand for industrial use



- Replacement lamps



Distributed by



Scitech
imaging specialists



MEL: (03) 9480 4999
SYD: (02) 9705 8059
sales@scitech.com.au
www.scitech.com.au

The Cooke Corporation
6930 Metroplex Drive
Romulus, Michigan 48174
Tel (248) 276-8820 Fax (248) 276-8825
info@cookecorp.com